

VALVES



FLO-TITE Direct Connect (DC)

VS



Direct Mount (DM)

Valve Top Works offers a choice of one or two ISO 5211 FO bolt patterns.

BOLT Pattern Most DM valves offer one bolt pattern.

Valve stems are marked to indicate flow direction.

FLOW INDICATOR

Most DM valves don't offer.

Live loaded STEM V-ring.

V-RING

V-ring packing only.

Easy packing adjustment without actuator removal, standard open-end wrench easy to adjust, PROBLEM FREE!

ACTUATOR ADJUSTMENT

Most valve actuators need to be removed from valve to adjust stem packing, special tool needed, VERY DIFFICULT!

Bolted adjustable packing design.

PACKING DESIGN

Threaded adjustable packing nut.

STEM leak detection windows prevent actuator damage in the event of valve stem leak.

LEAK DETECTION

Most DM valves do not offer.